



Screws

Nylon Machine Screws

Cheese Head	
8BA	$\frac{1}{8}"$ - $\frac{7}{8}"$
6BA	$\frac{3}{16}"$ - $1\frac{1}{4}"$
5BA	$\frac{1}{4}"$ - $\frac{3}{4}"$
4BA	$\frac{1}{2}"$ - $1\frac{1}{2}"$
3BA	$\frac{3}{4}"$ - $1"$
2BA	$\frac{3}{16}"$ - $2\frac{1}{2}"$
0BA	$\frac{1}{4}"$ - $2"$
$\frac{3}{16}"$ Whit	$\frac{1}{4}"$ - $1\frac{3}{8}"$
$\frac{1}{4}"$ Whit	$\frac{1}{4}"$ - $2"$
$\frac{5}{16}"$ Whit	$\frac{3}{8}"$ - $2\frac{3}{4}"$
$\frac{3}{8}"$ Whit	$\frac{1}{2}"$ - $2\frac{3}{4}"$
$\frac{1}{2}"$ Whit	$1\frac{1}{2}"$
M2.5	2.5 - 20mm
M3	3 - 30mm
M4	6 - 40mm
M5	6 - 50mm
M6	5 - 75mm
M8	10 - 80mm
M10	20 - 100mm
Pan head	
M3	3 - 30mm
M4	6 - 40mm
M5	6 - 50mm
M6	5 - 75mm
M8	10 - 80mm
M10	20 - 100mm
Round head	
8BA	$\frac{1}{4}"$ - $\frac{1}{2}"$
6BA	$\frac{1}{4}"$ - $1"$
4BA	$\frac{1}{4}"$ - $1\frac{1}{2}"$
3BA	$\frac{3}{8}"$
2BA	$\frac{1}{4}"$ - $1"$
0BA	$\frac{1}{4}"$ - $1\frac{1}{2}"$
$\frac{3}{16}"$ Whit	$\frac{1}{4}"$ - $1\frac{3}{8}"$
$\frac{1}{4}"$ Whit	$\frac{1}{4}"$ - $2"$
$\frac{5}{16}"$ Whit	$\frac{3}{8}"$ - $1"$
$\frac{3}{8}"$ Whit	$1"$
Hexagon head	
M3	3 - 30mm
M4	6 - 40mm
M5	6 - 50mm
M6	5 - 75mm
M8	10 - 80mm
M10	20 - 100mm
M12	20 - 100mm
M16	40 - 110mm

Countersunk head	
$\frac{3}{8}"$ Whit	$1"$ - $1\frac{1}{2}"$
M3	6 - 30mm
M4	6 - 35mm
M5	8 - 40mm
M6	8 - 60mm
M8	16 - 70mm
M10	25 - 80mm
Raised Countersunk head	
8BA	$\frac{1}{8}"$ - $\frac{3}{4}"$
6BA	$\frac{3}{16}"$ - $1"$
4BA	$\frac{3}{16}"$ - $1\frac{1}{2}"$
2BA	$\frac{1}{4}"$ - $1\frac{1}{2}"$
0BA	$\frac{1}{4}"$ - $1\frac{1}{4}"$
$\frac{3}{16}"$ Whit	$\frac{3}{8}"$ - $1"$
$\frac{1}{4}"$ Whit	$\frac{5}{16}"$ - $2"$
$\frac{5}{16}"$ Whit	$\frac{3}{8}"$ - $1\frac{1}{2}"$
M3	6 - 30mm
M4	6 - 35mm
M5	8 - 40mm
M6	8 - 60mm
M8	16 - 70mm
M10	25 - 80mm
Finger screws	
2BA	$\frac{1}{2}"$ - $1"$
0BA	$\frac{3}{4}"$
$\frac{1}{4}"$ Whit	$\frac{5}{8}"$ - $\frac{3}{4}"$
M5	6 - 30mm
M6	10 - 30mm
Isocoles head	
2BA	$\frac{1}{2}"$
$\frac{1}{4}"$ Whit	$\frac{1}{2}"$ - $1"$
$\frac{5}{16}"$ Whit	$\frac{3}{4}"$
Grub screws	
3BA	$\frac{3}{16}"$
2BA	$\frac{1}{4}"$ - $\frac{3}{8}"$
$\frac{3}{16}"$ Whit	$\frac{5}{16}"$
$\frac{1}{4}"$ Whit	$\frac{1}{4}"$ - $\frac{1}{2}"$
$\frac{5}{16}"$ Whit	$\frac{5}{16}"$ - $\frac{1}{2}"$
$\frac{3}{8}"$ Whit	$\frac{5}{16}"$ - $\frac{1}{2}"$
M4	5 - 12mm
M5	6 - 16mm
M6	5 - 30mm
M8	8 - 40mm
M10	20 - 25mm
M12	15 - 40mm

Polypropylene Machine Screws

Cheese head	
M6	30 - 50mm
M8	12 - 50mm
M10	25 - 40mm
Countersunk head	
M12	25 - 50mm
Hexagon head	
M6	25 - 75mm
M8	25 - 40mm
M10	25 - 65mm
M12	25 - 75mm
M16	40 - 75mm
M20	35 - 75mm

Polyacetal Wood Screws

Countersunk head	
M4	15 - 40mm
M5	15 - 50mm
M6	20 - 60mm
Raised countersunk head	
M4	15 - 40mm
M5	15 - 50mm
M6	20 - 60mm
Round head	
M4	15 - 40mm
M5	15 - 50mm
M6	20 - 60mm